

کیف پیک نیک



Picnic bag

سایز با درب: ۳۵ x ۳۵ x ۲۰
۳۵ x ۳۵ x ۲۵

سایز بی درب: ۳۵ x ۳۵ x ۲۰
۳۵ x ۳۵ x ۲۵

Size with door: 35 x 35 x 20
35 x 35 x 25

Size without door: 35 x 35 x 20
35 x 35 x 25



2198-1



2198



2199



2199-1



2200



2201





2202



1



2204-1



2204



2194-1



2141



2142




2143



2192-1




2192



2145




2178




2239




2425




2276-1



2276




2730




2611




2705



2714





2256



2729



2734



2733



2210



1572



2731




2217



2732



2445



2434



2447



2461



2463



2704

